



## Power HUB-16 RACE Input Switch Configuration Sheet

### Connector 'D'

Pin Number:	Pin Configuration:	Switches OUTPUT:
2	Master Switch ON/OFF (+12V)	ALL OUTPUTS OFF
3	IGN Input 1 (+12v trigger)	IGN 1 - PLUG "C", PIN 1 & 2 IGN 2 - PLUG "C", PIN 11 & 12
4	IGN Input 2 (+12v trigger)	IGN 3 - PLUG "C", PIN 3 & 4 IGN 4 - PLUG "C", PIN 9 & 10
7	STARTER Input (+12v trigger)	STARTER OUT - Plug "D", Pin 12
8	TRANS/CLUTCH Input (+12v trigger)	Transbrake OUT - Plug "D", Pin 11
9	General Purpose Input / Output 2	General Purpose Input / Output 2
10	General Purpose Input / Output 1	General Purpose Input / Output 1

### Connector 'B'

Pin Number:	Pin Configuration:	Switches OUTPUT:
1	AUX 1 Input (Trigger -ve)	AUX 1 - Plug "A", Pin 1 & 2
2	AUX 2 Input (Trigger -ve)	AUX 2 - Plug "A", Pin 3 & 4
3	AUX 3 Input (Trigger -ve)	AUX 3 - Plug "A", Pin 5 & 6
4	AUX 4 Input (Trigger -ve)	AUX 4 - Plug "A", Pin 11 & 12
5	AUX 5 Input (Trigger -ve)	AUX 5 - Plug "A", Pin 10
6	AUX 6 Input (Trigger -ve)	AUX 6 - Plug "A", Pin 9
7	AUX 7 Input (Trigger -ve)	AUX 7 - Plug "A", Pin 8
8	AUX 8 Input (Trigger -ve)	AUX 8 - Plug "A", Pin 7
9	ACC 1 / IGN 5 Input ( Trigger -ve )	IGN 5 / ACC 1 - Plug "C", Pin 5 & 6
10	ACC 2 / IGN 6 Input ( Trigger -ve )	IGN 6 / ACC 2 - Plug "C", Pin 7 & 8
11	TRANS/CLUTCH Input (Trigger -ve)	Transbrake OUT - Plug "D", Pin 11
12	STARTER Input (Trigger -ve)	STARTER OUT - Plug "D", Pin 12